



Screws and washers are located in the holes. Use Allen Wrench to back them out for assembly.